




Paul SuperTEC Zoom or Lecture Capture - Camera/Mic Selection Steps

1. Go to the Camera Icon located on the AV Touch Panel Source Selection Bar.
2. Choose the Camera you would like to use: Front or Rear facing
3. Choose the Camera Angle: Wide Angle, Motion Tracking, or Focused area
4. Next select your Source: Built in PC, or Personal Windows Laptop (connected with HDMI and the lectern USB cables).

(Note: DO NOT USE Zoom / Lecture capture with Built in Mac Computer or personal Mac Laptop in Paul College rooms)

5. Select your display mode: Instructor only or Audiovisual, be sure camera box is checked. If camera box is NOT checked off, use your finger to select the camera box.



6. For Zoom: Use the ^ to select the **Blackmagic Web Presenter** Camera and Microphone
7. For Lecture Capture: Select the **Blackmagic Web Presenter** Camera and Microphone
8. You should now be connected to the room camera and microphone.

Camera Modes and Angles

For camera use you must first go to the camera source icon on the touch panel.

Choose the camera application mode, then select your source. (HDMI / PC).

You will need to select the **Blackmagic Web Presenter** Camera and Microphone within the Zoom or Lecture Capture application.


 - Wide Angle Mode

 - Motion Tracking Mode

 - Focused Area Mode

You can change the camera's pan and tilt by tapping within the camera source screen.




Zoom In 

Zoom Out 

Mic: Blackmagic Web Presenter

Speaker: Crestron (Intel(R) Display Audio)



Example From Zoom