




## Paul SuperTEC Zoom or Lecture Capture - Camera/Mic Selection Steps

1. Go to the Camera Icon located on the AV Touch Panel Source Selection Bar.
2. Choose the Camera you would like to use: Front or Rear facing
3. Choose the Camera Angle: Wide Angle, Motion Tracking, or Focused area
4. Next select your Source: Built in PC, Built in Mac, or Personal Windows Laptop, Mac Laptop (connected with HDMI and the lectern USB cables).
5. Select your display mode: Instructor only or Audiovisual, be sure **camera box is checked**. If camera box is NOT checked off, go back to the camera icon on the touch panel, then back to your display source. Check off the box for Camera



6. For Zoom: Use the ^ to select the **#### INOGENI - 4KXUSB3** Camera and Microphone
7. For Lecture Capture: Select the **#### INOGENI - 4KXUSB3** Camera and Microphone
8. You should now be connected to the room camera and microphone.

### Camera Modes and Angles

**For camera use you must be sure the Camera checkbox is selected on your source subpage.**

Choose the camera application mode, then select your source. (HDMI / PC / Mac).

You will need to select the **#### INOGENI - 4KXUSB3** Camera and Microphone within the Zoom or Lecture Capture application.



- Wide Angle Mode



- Motion Tracking Mode



- Focused Area Mode

You can change the camera's pan and tilt by tapping within the camera source screen.



Zoom In



Zoom Out



**Mic: #### INOGENI - 4KXUSB3**

**Speaker: Crestron (Intel(R) Display Audio**



Example From Zoom